OVEN SOFTWARE UNINSTALLATION ON WINDOWS-XP: -

1. BACKUP SETUP PARAMETERS AND RECIPE FILES

- a. Run Oven System Setup Wizard (Start -> Programs -> Oven (or Heller) Workstation
 -> System Setup Wizard) and write down all the setup parameters from all the pages of the setup program.
- b. Using Windows Explorer backup all existing recipes from C:\Oven\Recipe Files folder or C:\Heller\Recipe Files to a floppy disk or a temporary backup folder. Also backup OVEN.SYS file from C:\Oven\System Files (or C:\Heller\System Files) folder

2. UNINSTALL EXISTING OVEN SOFTWARE

- a. From CONTROL PANEL double left mouse click on ADD/REMOVE PROGRAMS. From the list select "Oven Workstation ..." or "Heller Workstation ..." and left mouse click on the REMOVE button.
- b. On the confirmation message window left mouse click "YES".
- c. Using Windows Explorer delete C:\OVEN or C:\HELLER folder. Right mouse click on the folder then choose Delete.
 - Delete folder "Oven Backup Files" or "Heller Backup Files" from "c:\windows\system32\" folder.
 - Delete file xpDriver.sys from "c:\windows\system32\drivers" folder for HC1-x controller oven.
 - Search files "WIN_HDAC.DLL" & "Heller comm.ocx" from
 - "c:\windows\system32\" folder and make sure to delete them if found.
- d. Restart the computer and check COM1 in device manager for HC1-x controller oven. From CONTROL PANEL select "System", and then select "Device Manager" in "Hardware" tab. From the "Ports" list check the Communications Port (COM1) is available. "Oven_Board (COM1)" or "Heller_Board (COM1) should not be present.
- e. To install oven software follow separate installation instructions.

OVEN SOFTWARE UNINSTALLATION ON WINDOWS-98: -

BACKUP FILES AND PARAMETERS

- a. Run Heller System Setup Wizard (Start -> Programs -> Heller Workstation -> System Setup Wizard) and write down all the setup parameters from all pages of the setup program.
- b. Using Windows Explorer backup all existing recipes from C:\Heller\Recipe Files folder to a floppy disk or network drive.
- c. To upgrade to Windows-XP OS install it by formatting hard drive. Make sure computer is compatible for Windows-XP, have at least 256MB RAM and processor speed at least 1Ghz. (Heller Industries is not responsible for supplying Windows-XP OS.)
- d. To install oven software follow separate installation instructions.